

Prestigio



GEOVISION 5055



You may find detailed warranty information at: www.prestigio.com/support/warranty-terms.

© Copyright 2015 Prestigio. All rights reserved.




Unboxing




Inside your package
Your device at a glance

Inside your package



- Prestigio GPS
- Mounting cradle
- Car charger
- USB cable
- Quick start guide
- Warranty card

Your device at a glance



- | | |
|------------------|------------------|
| 1. Power button | 4. Mini USB port |
| 2. Earphone jack | 5. Reset button |
| 3. SD card slot | 6. Speaker |



Getting started



Install memory card
Mount your device
Charge the battery
Power on your device

Congratulations on your purchase and welcome to Prestigio. To get the most from your product and enjoy all that Prestigio has to offer, please visit:


<http://www.prestigio.com/catalogue/Navigators>

For more details about your product, please visit:

www.prestigio.com/support


Install memory card

Before power on, please insert a microSD card (not included) into the slot until it locks in place.



The device will automatically recognize it as default storage, and save mapping data or user's music, photo or video on this card.

Mount your device



1. Install the bracket to mounting cradle.
2. Remove the protection plastic film from the suction cup, and position it on the clean windshield or dashboard.
3. Hold firmly against the surface and lock the suction cup lever. The mount will suction and stick firmly onto the surface.
4. Lock device on the bracket with bottom on the appropriate socket.
5. Rotate the knob to adjust device to desired viewing angle.



Make sure that the device has a clear view of sky to attain best GPS reception.




Install memory card
Mount your device
Charge the battery
Power on your device

Dismount your device

1. Push the tap on top of the mounting cradle to release the device.
2. Lift the suction cup lever to easily remove the suction cup from windshield or dashboard.

Charge the battery

- Using the car charger: after vehicle engine is started, charge the device through vehicle 12V cigarette lighter, to protect the device from sudden surges in current.
- Using mini USB cable: connect the device to AC adapter or the USB port of a computer.



- Please fully charge the battery (for at least 8 hours) before initial use. The battery status indicator glows in red color when charging, and turns bright amber color when charging is complete.
- Charging time is approximately 2 hours after initial use.
- It is not necessary to start charging the device before the battery is fully discharged.

Power on your device

Press and hold the power button to turn on your device.



To turn it off, press and hold the power button, and then tap power icon on the pop-up screen.



Maps & navigation




GPS modes

Navigation menu

Navigation

Map screen

GPS modes



When Prestigio GeoVision is started the first time, you need to select whether to start the program in Simple mode or in Advanced mode.

The two operating modes of Prestigio GeoVision mainly differ in the menu structure and the number of available features. The controls and screen layouts are the same.

- Simple mode: you have easy access to the most important navigation functions and the basic settings only. The rest of the settings are set to values that are optimal for typical use.

- Advanced mode: you have access to the full functionality of Prestigio GeoVision. This manual covers actions in Simple mode.

Later you can switch between the two operating modes:

- To switch from Simple mode to Advanced mode: on the startup screen (Navigation Menu), tap **Settings** > **Advanced mode**.
- To switch from Advanced mode to Simple mode: on the startup screen (Navigation Menu), tap **Settings** > **Simple mode**.



GPS modes

Navigation menu

Navigation

Map screen

Navigation menu



After selecting Simple mode, the Navigation menu appears. From here you can reach all parts of Prestigio GeoVision.

The Navigation menu contains the following options:

- Tap **Find Address** to specify an address as your destination.
- Tap **History** for the list of recent destinations.
- Tap **Find POI** to select one of the stored Points of Interest.
- Tap **Favourites** for the list of your favourite

destinations.

- Tap **Map** to navigate or to browse the map.
- Tap **Settings** to customise the way Prestigio GeoVision works.
- Tap **Exit** to stop navigation, and exit Prestigio GeoVision.




GPS modes

Navigation menu

Navigation

Map screen

Navigation




- In the Navigation menu, tap **Find Address**.
By default, Prestigio GeoVision proposes the country/state and settlement where you are.
If needed, tap the button with the name of the country/state, and select a different one from the list. If needed, change the settlement:
- To select the settlement from the list of recently used ones, tap the  button.
 - To enter a new settlement:
1. Tap the button with the name of the settlement, or if you have changed the country/

- state, tap **City name**.
2. Start entering the settlement name on the keyboard.
3. Get to the list of search results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap **Done** to open the list of results before it appears automatically.
4. Pick the settlement from the list.



GPS modes
Navigation menu
Navigation
Map screen



Enter the street name:

1. Tap **Street name**.
2. Start entering the street name on the keyboard.
3. Get to the list of results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap **Done** to open the list of results before it appears automatically.
4. Pick the street from the list.

Enter the house number:


1. Tap **House number**.
2. Enter the house number on the keyboard.

3. Tap **Done** to finish entering the address.

The map appears with the selected point in the middle. Tap **Navigate to** from the Cursor menu. The route is then automatically calculated, and you can start navigating.



GPS modes
Navigation menu
Navigation
Map screen



On the Map screen, tap **Menu** to return to the Navigation menu.

In the Navigation menu, tap **Find POI**.


Select the area around which the POI should be searched:

- **Around address:** The POI will be searched around a given address.
- **Around cursor:** The POI will be searched around the Cursor.
- **Around GPS position:** The POI will be searched around the current GPS position.
- **Around destination:** The POI will be searched around the destination of the active route.
- **Along route:** The POI will be searched not around a given point but by the size of the

detour it means from the active route. This can be useful if you search for a later stopover that causes only a minimal detour. For example upcoming petrol stations or restaurants. After this, the list of POI categories appear.



GPS modes
Navigation menu
Navigation
Map screen



You can narrow the search with the following:

- Select the POI group (e.g. Accommodation), and after that, if needed, select the POI subgroup (e.g. Hotel or Motel).
- To find the POI by its name, tap **Search**, and use the keyboard to enter a part of the name.
- To list all POIs in a given POI group, press **Search**, and then **Done** without entering any letters of its name.

[optional] When finally the list of results appear, you can change the list order with the **Order by name** or **Order by detour** button.

Tap the desired POI in the list.

The map appears with the selected point in the middle. Tap **Navigate to** from the Cursor menu. The

route is then automatically calculated, and you can start navigating.



GPS modes
Navigation menu
Navigation
Map screen

Map screen



The most important and most often used screen of Prestigio GeoVision is the Map screen. The map looks similar to a conventional road-map. The blue arrow represents your current position, and the green line shows the recommended route. There are several screen buttons and data fields on the screen to help you navigate. Their functions are explained in detail in the User Manual. During navigation, the screen shows route information and trip data (left screenshot), but when you tap the map, additional buttons and controls appear for a few seconds (right screenshot). Most parts of the screen behave as buttons.

2D or 3D: Switches between 2D (classic top-down view) and 3D (perspective view for navigation) map modes.

Menu: Opens the Navigation menu.

If you have moved the map, a  button appears. Tap this button to move the map back to the current GPS position.



Specifications



**MSB2531A Cortex A7,
800 MHz**



RAM 128 MB + 4 GB Flash



Micro SDHC/SDXC ≤ 32GB



5" touch LCD, 480*272



1050 mAh



137.5*88.5*12.5 mm (H*W*D)



170 g



Troubleshooting



Take steps described in the tables below to solve simple problems before contacting customer service.



Immediately turn off the device and disconnect the power adapter if the device is not working properly. Never try to repair the unit without authorized professionals for it may damage the unit.

Users can't turn on the unit.

- Connect the adaptor correctly.
- Use the adaptor to supply power or charge the battery.

There is no sound.

- Turn up the volume or turn on the sound output.

There is no picture.

- Adjust the brightness of the LCD.

The unit can't receive satellite signals or can't orient.

- Make sure to use the unit out of room; if in the

vehicle, you can use the external GPS antenna to solve this problem.

The unit can receive signals now but can't then; signals received are not stable.

- Use the adaptor to supply power or charge the battery.
- Remove the veil.
- Avoid great swing of the unit.



Safety instructions



- To reduce the risk of electric shock, do not remove the cover (or back). Only PRESTIGIO certified technicians are qualified to repair your device.
- The manufacturer should not hold responsibility for the damage caused by any substitutions and modifications of the product without authorization from the manufacturer or authorized unit.
- To prevent fire or shock hazard, do not expose your device to rain or moisture.
- Do not put, store or leave your device near heat sources, in direct strong sunlight, or in a high temperature location.
- Maintain well-ventilated conditions around the unit to avoid overheating.
- Operating temperature: -20°C to 60°C.